



dreamGEAR[®]
www.dreamgear.net

Package Contents:

- GameBlaster
- Micro Racing Wheel
- Game Grip
- Baseball extension
- Tennis extension
- Golf extension
- Extension cradle

GameBlaster instructions:

1. Place your Wii remote and nunchuck into the GameBlaster's casing by setting the Wii remote into the GameBlaster's barrel casing and the Wii nunchuck into the GameBlaster's handle.


- Open the lid on the GameBlaster.
- Place the Wii remote into the GameBlaster's barrel casing.
- Place the Wii nunchuck into the GameBlaster's nunchuck casing.

2. Close the lid on the GameBlaster.


3. You are now ready to enjoy your GameBlaster with your favorite 1st person shooter or shooting games.



Break-away design for
tricky in-game moves



Rotating barrel for
complete control



For left or right
handed players

Micro Racing Wheel instructions:

1. Place your Wii remote into the Micro Racing Wheel (the Wii remote's directional pad should be on the left side).
2. The Micro Racing Wheel features an infrared pass-thru, which allows you to make on-screen selections without removing the Wii remote from the Micro Racing Wheel.



Game Grip instructions:

1. Place your Wii remote into the Game Grip's remote slot. Attach handles by sliding them onto the remote slot from the bottom.
2. Attach analog stick by snapping it onto the remote slot directly over the directional pad on your Wii remote.



Sports extension instructions:

1. Place your Wii remote into the remote slot.
2. Depending on which game you are playing, choose the appropriate remote extension.
3. With your Wii remote connected to the remote slot, attach the Tennis Racket, Golf Club, or Baseball Bat to the remote slot by screwing the extension of choice into the remote slot.



dreamGEAR[®]
www.dreamgear.net

FOR TECHNICAL SUPPORT
PLEASE CONTACT: 1-877-999-DREAM
or support@dreamgear.net